

# Quick Guide

**Flexible Zuführung  
aflex 400 lv  
Revision A**



# Quick Guide 1. Preparation



## 1 check packaging



## 2

- aflflex configurations
- aflflexConfigurator\_1\_57
- ControlUnit backup
- documentation
- FirmwareFiles
- production test document.pdf



## 3 check test document









## 4 Tool list

- Torque handle (min. 10Nm)
- Hex bit 8mm
- screwdriver

## 5 Dimension of base plate




# Quick Guide 2. Mechanical Assembling








# Quick Guide 3. Control Assembling





condition as supplied



or



# Quick Guide 4. Electrical Wiring



# Quick Guide 5. Software

**1 Software location**

- aflex configurations
- aflexConfigurator\_1\_57**
- ControlUnit backup
- documentation
- FirmwareFiles
- production test document.pdf

**2 Install software**

**3 Connect ControlUnit**

**4 start software**

**5 connect**

**6**

**7 manual mode & general release**

**8 Need Help? use these Buttons**

**9**

**10 load configuration „1 | flipp“**

**11**

**12 use aflex control panel with mouse**

**13 Test sample parts on aflex**

**14 read user manual**

- aflex configurations
- aflexConfigurator\_1\_57
- ControlUnit backup
- documentation**
- FirmwareFiles
- production test document.pdf

# Quick Guide 6. Test electrical connection

**1 Menu aflex modules**

**2 open test site**

**3 start test**

Test the electrical Connection: Actuator <-> Channel Mapping

check connection

|                               |     | target          | actual        |
|-------------------------------|-----|-----------------|---------------|
| Driver Node 1<br>SN: 20000036 | CH1 | X Horizontal X- | Horizontal Y- |
|                               | CH2 | X Horizontal X+ | Horizontal Y- |
|                               | CH3 | X Horizontal Y+ | Horizontal Y- |
|                               | CH4 | ✓ Horizontal Y- | Horizontal Y- |
| Driver Node 2<br>SN: 20000163 | CH1 | X Vertical X-Y+ | Horizontal Y- |
|                               | CH2 | X Vertical X-Y- | Horizontal Y- |
|                               | CH3 | X Vertical X+Y- | Horizontal Y- |
|                               | CH4 | X Vertical X+Y+ | Horizontal Y- |

**4 successfull result**

Test the electrical Connection: Actuator <-> Channel Mapping

check connection

|                               |     | target          | actual        |
|-------------------------------|-----|-----------------|---------------|
| Driver Node 1<br>SN: 20000036 | CH1 | ✓ Horizontal X- | Horizontal X- |
|                               | CH2 | ✓ Horizontal X+ | Horizontal X+ |
|                               | CH3 | ✓ Horizontal Y+ | Horizontal Y+ |
|                               | CH4 | ✓ Horizontal Y- | Horizontal Y- |
| Driver Node 2<br>SN: 20000163 | CH1 | ✓ Vertical X-Y+ | Vertical X-Y+ |
|                               | CH2 | ✓ Vertical X-Y- | Vertical X-Y- |
|                               | CH3 | ✓ Vertical X+Y- | Vertical X+Y- |
|                               | CH4 | ✓ Vertical X+Y+ | Vertical X+Y+ |